

SLAB INSTALLATION GUIDELINES

Professional Fabrication Standards

EUROSTONE QUARTZ

Premium Surfaces

Pre-Installation

- Inspect all slabs for defects before fabrication
- Store slabs upright at 80-90 degree angle
- Acclimate material to job site temperature 24 hours before installation
- Verify all measurements against field dimensions
- Plan seam locations to minimize visibility

Substrate Preparation

- Cabinets must be level within 1/8" over 10 feet
- Provide solid support every 24 inches
- Use 3/4" plywood or equivalent substrate
- Ensure cabinets can support 25 lbs per square foot
- Leave 1/8" gap between substrate and walls

Cutting & Fabrication

- Use diamond-tipped blades designed for quartz
- Always wear appropriate PPE including respirator
- Use water when cutting to minimize dust
- Support material on both sides of cut
- Smooth all edges with diamond polishing pads

Adhesive & Installation

- Use 100% solids epoxy or polyester adhesive
- Apply adhesive in 2" diameter dots every 8-12 inches
- Additional support required for overhangs beyond 12 inches
- Clean all surfaces before applying adhesive
- Allow 24 hours cure time before use